



AMS FLAMMABLE STORAGE CABINET

The Flammable Liquid Storage Cabinet is a “cabinet-within-a-cabinet” design with fully welded 18ga interior and exterior units. Both cabinets are completely powder coated inside and out, offering greater protection against corrosion than the standard double panel construction. This airspace is filled with 1.5” thick insulation for extra heat resistance.

The interior of the cabinet contains one fully adjustable shelf and a 2” deep removable drip pan to capture any spills or leaks inside the cabinet. Exterior depth of the cabinet is 18” or 22” and interior depth is 14” or 18”. A 2” x 2” 12ga support angle is shipped with each cabinet for countertop installation.

Doors have a continuous hinge and lever type handles with a hidden 3-point lock mechanism. If a self-closing feature is required, a hydraulic closure will be attached to the doors and a custom closing system attached to the interior cabinet. The back of the cabinet has two venting holes that are plugged with 2” barrel bungs.

AMS Flammable Liquid Storage Cabinets are constructed in accordance with OSHA, NFPA 30 and are UL listed.

Cabinets are guaranteed against manufacturing defects and corrosion (under normal operating procedures) for 5 years.

